

LC8 Torque Chart

Pressure In PSI	Torque			Pressure In Bars
	FT.LBS.	KGM	NM	
1500	1350	188	1830	104
1600	1440	200	1952	110
1800	1620	225	2196	124
<hr/>				
2000	1800	250	2440	138
2200	1980	275	2684	152
2400	2160	300	2928	165
2600	2340	325	3172	179
2800	2520	350	3416	193
<hr/>				
3000	2700	375	3660	207
3200	2880	400	3904	220
3400	3060	425	4148	234
3600	3240	450	4392	248
3800	3420	475	4636	262
<hr/>				
4000	3600	500	4880	276
4200	3780	525	5124	290
4400	3960	550	5368	303
4600	4140	575	5612	317
4800	4320	600	5856	331
<hr/>				
5000	4500	625	6100	345
5200	4680	650	6344	358
5400	4860	675	6588	372
5600	5040	700	6832	386
5800	5220	725	7076	400
<hr/>				
6000	5400	750	7320	414
6200	5580	775	7564	427
6400	5760	800	7808	441
6600	5940	825	8052	455
6800	6120	850	8296	468
<hr/>				
7000	6300	875	8540	482
7200	6480	900	8784	496
7400	6660	925	9028	510
7600	6840	950	9272	524
7800	7020	975	9516	538
<hr/>				
8000	7200	1000	9760	552
8200	7380	1025	10004	565
8400	7560	1050	10248	579
8600	7740	1075	10492	593
8800	7920	1100	10736	607
<hr/>				
9000	8100	1125	10980	620
9200	8280	1150	11224	634
9400	8460	1175	11468	648
9600	8640	1200	11712	662
9800	8820	1225	11956	676
10000	9000	1250	12200	690

IMPORTANT SAFETY INSTRUCTIONS

WARNING: Your **HYTORC TORQUE MACHINE** is a power tool, and as with any power tool, certain safety precautions should be observed to avoid accidents or personal injury. The following tips will assist you.

- **READ ALL INSTRUCTIONS.**
- **KEEP WORK AREA CLEAN AND WELL LIT.**
- **CONSIDER WORK AREA ENVIRONMENT.** Electrical Pumps should never be used in an atmosphere which can be considered potentially volatile. If there is any doubt, use an air pump. Also Note: metal to metal contact can cause sparks, precautions should be taken.
- **AVOID PREMATURE TOOL STARTING.** The Pump Remote Control is for the **TOOL OPERATOR** only.
- **STAY CLEAR DURING OPERATION.** In most cases, the tool will allow “hands free” operation. If the tool must be held or steadied during operation, use alternative means of securing the tool to the application
- **GUARD AGAINST ELECTRIC SHOCK.** Ensure the pump is properly grounded and the proper voltage is being used.
- **STORE IDLE TOOLS.** When not in use, tool and accessories should be properly stored to avoid deterioration
- **USE RIGHT TOOL.** Don't force small tools or attachments to do the job of a larger tool. Don't use a tool for purposes not intended.
- **PROPER SAFETY ATTIRE.** When handling/operating hydraulic equipment use work gloves, hard hats, safety shoes and other applicable clothing.
- **USE SAFETY GLASSES.**
- **MOVING EQUIPMENT.** Do not use hydraulic hoses, uni-swivels, pump power or remote cords as means of moving the equipment.
- **MAINTAIN TOOLS WITH CARE.** For top performance, inspect tools, powerpack and accessories for visual damage frequently and always prior to use. Always follow instruction for proper tool and pump maintenance. Refer to the Operations Maintenance Section for further clarification
- **STAY ALERT.** Watch what you are doing. Use Common sense. Do not use power equipment under the influence of any mood altering substances.
- **PRIOR TO OPERATION**
Ensure that all hydraulic connections are securely connected and there is no leakage
Verify that the Hydraulic hoses are not kinked or otherwise damaged.
Ensure the square drive and its retainer are fully and securely engaged.
Be certain that all connectors, elbows, fitting and swivels are not bent, loose or damaged.
- **PRIOR TO USE.**
Check sockets for size, quality and flaws. (Do not use if questionable)
Cycle tool to ensure proper function.
Locate a solid, secure reaction point.
Be sure the reaction arm retaining clamp is fully engaged.
Be sure the hydraulic hoses are free of the reaction point.
Pressurize the system momentarily; if the tool tends to “ride up” or to “creep”, stop and re-adjust the reaction arm to a more solid and secure position.

NOTE: Remain clear of the reaction arm during operation and never put body parts between reaction arm and reaction surfaces.

- **ALWAYS USE QUALITY ACCESSORIES.** Always use top quality impact sockets in good condition which are the correct size and fully engage the nut. Hidden flaws, however, remain a possibility which could cause breakage, so stay clear of sockets during operation
- **DO NOT USE** other equipment to enhance performance (Hammer on Socket/Tool)

NOTE: Hytorc Pumps are designed to operate Hytorc Tools only. Damage may occur to the pump or the product that is being operated due to misuse.

SAVE THESE INSTRUCTIONS FOR FUTURE USE!